

*Uddery  
Love*

# Milk Contact Surface Cleaning Protocol

- STEP 1** Clean off large particles with warm water (32°C)
- STEP 2** Manually wash with a brush for 1–2 minutes with hot water (60°C) mixed with a chlorinated alkaline detergent (pH 11–12) such as Matrix BioClean Base.
- STEP 3** Rinse with cold water
- STEP 4** Rinse a second time with an acidic solution (pH 2–3)
- STEP 5** Let dry
- STEP 6** Sanitize inside and outside of calf feeding equipment within 2 hours of use
- STEP 7** Consult your Matrix representative to ensure proper removal of biofilm. Target: 30 RLU and under.

